

VULCAN VENT® FIRE & EMBER SAFE VENTS

STOPS FIRES

PROUDLY DISTRIBUTED BY

BMD

An Employee Owned Company

WWW.BMDUSA.COM/VULCANVENTS



RETRO-FIT INSTALLATION GUIDE

Installation of Vulcan Reto-fit Vents are as easy as 1-2-3. Typical tools required: Hammer or Screw Driver, Ladder (not all projects will require the use of ladders), nails or screw fasteners.

STEP 1: REMOVE OLD VENT (DORMER RETRO-FIT INSTALLS OVER EXISTING)

STEP 2: REPLACE WITH VULCAN VENT STEP 3: FASTEN WITH NAILS OR SCREWS

CAUTION: Remember to use extreme caution during the installation process. Secure the ladder firmly and use care. Ladder falls account for over 20% of work related accidents. Maintain safe working practices at all times and do not attempt if you are not in physical shape to do so.

VULCAN EAVE VENT RETRO-FIT UPGRADE







VULCAN FOUNDATION VENT RETRO-FIT UPGRADE







VULCAN DORMER VENT RETRO-FIT UPGRADE











NOTES	
As a second seco	
A CONTRACTOR	







BMD, INC. 225 ELM AVE. GALT, CA 95632

(800)545-0365 WWW.BMDUSA.COM/VULCANVENTS PROUDLY DISTRIBUTED BY



Building Material Distributors, Inc.

An Employee Owned Company